
Recommendations to order spare parts

Please try to determine the exact designations of the spare parts for your order using the maintenance manual. This is to guarantee a fast and correct delivery of the parts.

The designations are to find in the sections system description, instructions for assembly and servicing work and especially in the diagrams of the maintenance manual.

Yours sincerely
DG Aviation GmbH



Dipl, Ing. W. Dirks

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

0 General

0.1 Amendments

No.	Page	Description	Date
0.1	all	Combination of the initial Maintenance Manuals of the Variants DG-300, DG-300 ELAN, DG-300 ELAN ACRO, DG-300 Club ELAN and DG-300 Club ELAN ACRO, new standardized format	December 2009
0.2	0.7, 1.10, 1.12, 2.1, 2.4, 3.2, 4.1, 4.2, 5.1, 5.2, 6.1, 6.2	Miscellaneous changes to the contents of the latest amendments of the initial maintenance manuals	December 2009
1	0.1, 0.3 – 0.8, 1.4, 2.1, 6.3, 8.8 – 8.12, 9.9 – 9.12	TN DG-SS-05 Manual revision Inclusion of TN359/4 and TN359/24	August 2020
2	0.1, 0.3, 1.2, 1.3	TN DG-SS-09 adjustment of elevator free play	December 2023
3	0.1, 0.4, 6.3	TMDG-G-16 Accelerometer LXNAV G-meter	April 2024
4	0.1,0.3, 0.4, 0.6, 4.6, 6.1, 8.8 - 8.14	TN 359/17 Revision 1 Wingtips with winglets and TN DG-SS-08 neo winglets	November 2024
5	Cover page, 0.1	TN DG-G-17 Update of cover page	August 2025
6	0.0, 0.1, 0.3, 0.4, 0.6, 8.15	TM DG-SS-10 Control column, control stick suspension, securing the spherical bearings	September 2025

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

0.2 List of effective pages

Section	page	issued	replaced	replaced	replaced
0	0.0	December 09	September 25		
	0.1	see manual amendments			
	0.2		"		
	0.3		"		
	0.4		"		
	0.5	December 09	August 20		
	0.6	"	August 20	November 24	September 25
	0.7	"	August 20		
	0.8	August 20			
1	1.1	December 09			
	1.2	"	December 23		
	1.3	"	December 23		
	1.4	"	August 20		
	1.5	"			
	1.6	"			
	1.7	"			
	1.8	"			
	1.9	"			
	1.10.	"			
	1.11	"			
	1.12	"			
2	2.1	December 09	August 20		
	2.2	"			
	2.3	"			
	2.4	"			
	2.5	"			
	2.6	"			
3	3.1	December 09			
	3.2	"			
	3.3	"			

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

List of effective pages (cont.)

Section	page	issued	replaced	replaced	replaced
4	4.1	December 09			
	4.2	"			
	4.3	"			
	4.4	"			
	4.5	"			
	4.6	"	November 24		
	4.7	"			
	4.8	"			
5	5.1	December 09			
	5.2	"			
6	6.1	December 09			
	6.2	"			
	6.3	"	August 20	April 24	
7	7.1	December 09			
Diagrams					
8	8.1	December 09			
	8.2	"			
	8.3	"			
	8.4	"			
	8.5	"			
	8.6	"			
	8.7	"			
	8.8	"	August 20	November 24	
	8.9	"	August 20	November 24	
	8.10	"	August 20	November 24	
	8.11	"	August 20	November 24	
	8.12	August 20	November 24		
	8.13	November 24			
	8.14	November 24			
	8.15	September 25			
Enclosures					
9	9.1	31.01.84			
	9.2	19.08.87			
	9.3	December 09			
	9.4	"			
	9.5	"			
	9.6	"			
	9.7	Dec. 84			
	9.8	Oct. 87			
	9.9 -9.12	August 20			

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

Section content page
4 Detailed instructions for assembly and servicing work 4.1
4.1 Replacement of the water ballast bags 4.1
4.2 Replacement of control circuit cables 4.1
4.3 Adjustment work on the control circuit 4.2
4.4 Removal and installation of the retractable landing gear 4.2
4.5 Removal and installation of the fix landing gear 4.3
4.6 Removal and reinstallation of the ailerons 4.4
4.7 Increasing the aileron massbalancing 4.7
4.8 Fixing excessive free play of the canopy 4.8
5 Centre of Gravity measurements-weighing 5.1
6 Instrument- und equipment list 6.1
6.1 Air speed indicator (0 - 300 km/h, 165 kts) 6.1
6.2 Altimeter 6.1
6.3 Harness (seat) 6.1
6.4 Compass (as min. equipment only necessary for cloud flying) 6.2
6.5 VHF transceiver 6.2
6.6 Variometer (as min. equipment only necessary for cloud flying) 6.2
6.7 Turn and bank indicator (as min. equipment only necessary for cloud flying) 6.2
6.8 Outside air temperature gauge 6.3
6.9 Beschleunigungsmesser 6.3
6.10 Instruments which are not part of the minimum equipment: 6.3
7 Liste der Spezialwerkzeuge 7.1
8 Diagrams 8.1
Diagram 1 Elevator control circuit, adjustment 8.1
Diagram 2 Rudder control circuit, retractable landing gear 8.2
Diagram 3 Fix landing gear 8.3
Diagram 4 Aileron and spoilers control circuits, wheel brake 8.4
Diagram 5 Tow hook, water ballast release systems DG-300, DG-300 ELAN, DG-300 ELAN ACRO 8.5
Diagram 6 Tow hook, water ballast release systems DG-300 Club ELAN, DG-300 Club ELAN ACRO 8.6
Diagram 7 Empty weight centre of gravity range 8.7
Diagram 8 Placards DG-300 & DG-300 ELAN 8.8
Diagram 9 Placards DG-300 ELAN ACRO 8.9
Diagram 10 Placards DG-300 Club ELAN 8.10
Diagram 11 Placards DG-300 Club ELAN ACRO 8.11
Diagram 12 Placards if TN359/24 instruction A is applicable 8.11
Diagram 13 Placards with winglets if TN359/24 instruction A is applicable . 8.11
Diagram 14 Placards with winglets if TN359/24 instruction A is not applicable 8.11
Diagram 15 Additional control column afeguard acc. to TN DG-SS-10 8.15

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

Zusätzliche Sicherungen des Handsteuers gemäß TM DG-SS-10 bzw. TM 800/52
Additional control column safeguard according to TN DG-SS-10 resp. TN 800/52

diagram 15

