
Recommendations to order spare parts

Please try to determine the exact designations of the spare parts for your order using the maintenance manual. This is to guarantee a fast and correct delivery of the parts.
The designations are to find in the sections system description, instructions for assembly and servicing work and especially in the diagrams of the maintenance manual.

Yours sincerely
DG Aviation GmbH



Dipl.- Ing. W. Dirks

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

0 General

0.1 Manual amendments

No.	Page	Description	Date
0.1	all	Combination of the initial Maintenance Manuals of the Variants DG-200, DG-200/17 and DG-200/17C, new standardized format	December 2009
0.2	0.7, 1.1, 1.2, 1.7, 1.8, 1.10-1.12, 1.15-1.17, 1.20, 1.21, 1.26, 2.1-2.3, 4.3 – 4.6	Miscellaneous changes to the contents of the latest amendments of the initial maintenance manuals	December 2009
1	0.1, 0.3, 1.4, 1.23,	TN DG-SS-06 Manual revision	September 2020
2	0.1, 0.3, 1.25, 1.26	TN DG-SS-09 Adjustment of elevator free play	December 2023
3	Cover page, 0.1	TN DG-G-17 Update of cover page	August 2025
4	0.0, 0.1, 0.3, 0.4, 0.6, 3.12	TN DG-SS-10 Control column, control stick suspension, securing the spherical bearings	September 2025

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

0.2 List of effective pages

Section	page	issued	replaced	replaced	replaced
0	0.0	December 09	September 25		
	0.1	see manual amendments			
	0.2		"		
	0.3		"		
	0.4		"		
	0.5	December 09			
	0.6	"	September 25		
	0.7	"			
1	1.1	December 09			
	1.2	"			
	1.3	"			
	1.4	"	September 20		
	1.5	"			
	1.6	"			
	1.7	"			
	1.8	"			
	1.9	"			
	1.10.	"			
	1.11	"			
	1.12	"			
	1.13	"			
	1.14	"			
	1.15	"			
	1.16	"			
	1.17	"			
	1.18	"			
	1.19	"			
	1.20	"			
	1.21	"			
	1.22	"			
	1.23	"	September 20		
	1.24	"			
	1.25	"	December 23		
	1.26	"	December 23		
2	2.1	December 09			
	2.2	"			
	2.3	"			

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

List of effective pages (cont.)

Section	page	issued	replaced	replaced	replaced
Diagrams					
3	3.1	December 09			
	3.2	"			
	3.3	"			
	3.4	"			
	3.5	"			
	3.6	"			
	3.7	"			
	3.8	"			
	3.9	"			
	3.10	"			
	3.11	"			
	3.12	September 25			
Enclosures					
4	4.1	1.08.02			
	4.2	30.11.92			
	4.3	03/94			
	4.4	"			
	4.5	"			
	4.6	"			
	4.7	7.04.93			
	4.8	4.11.96			
	4.9	14.10.96			
	4.10	"			

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

3 Diagrams 3.1

Diagram	Content	page
1	Empty Mass C.G. (empty mass 240 – 280 kg)	3.1
2	Empty Mass C.G. (empty mass 2240 – 250 kg)	3.2
3	Airspeed Calibration	3.3
4	Placards	3.4
5	Difference in placarting for single piece canopy	3.5
6	Pattern for aileron adjustment	3.6
7	Aileron, flap and airbrake controls	3.7
8	Elevator control without automatic hook up	3.8
9	Elevator control with automatic hook up	3.9
10	Rudder control, landing gear without spring mounting	3.10
11	Rudder control, landing gear with spring mounting	3.11
12	Additional control column safeguard acc. to TN DG-SS-10,	3.12


4 Enclosures

Content	page
drawing 2R20 parking brake combined with Piggott-hook	4.1
Service Information 1/86-2 (Hotellier quick connectors)	4.2
L'Hotellier Instructions for the maintenance M 10.01	4.3
Service-information 0-4/92 Hotellier quick connectors securing sleeves	4.7
TN 301/18	4.8
Working instruction No. 1 for TN 301/18	4.9
Working instruction No. 2 for TN 301/18	4.10

Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only

Zusätzliche Sicherungen des Handsteuers gemäß TM DG-SS-10 bzw. TM 800/52
Additional control column safeguard according to TN DG-SS-10 resp. TN 800/52

diagram 12



Copyright DG Aviation GmbH - any copy or publishing prohibited
Manual valid with the up-to-date cover page only